Solenoid Disassembly









1. A CLOGGED DIAPHRAGM WILL CAUSE NOZZLES TO DRIP WHEN THE SYSTEM IS SHUT OFF.
2. OUR SOLENOID REPAIR KIT SKU: 30375-R

3. WHEN THE MISTING PUMP IS OFF, THE SOLENOID RESTRICTS WATER TO PASS THROUGH THE PUMP. IF WATER IS LEAKING OUT OF THE NOZZLES WHEN THE SYSTEM IS OFF, PLEASE SERVICE YOUR SOLENOID.